

User Guide Stepping motor drive Series

Models

PROFINET



HT7_PROFINET_rev8_eng

S.H.S. s.r.l. Via F.lli Rosselli, 29 20027 Rescaldina (MI) – ITALY

Tel. +39 0331 466918 Fax. +39 0331 466147 www.shsitalia.it





The SHS automation products should be handled, installed and maintained by qualified personnel trained on installation of automation components, and only for the purposes described in the user manual. Installers must pay particular attention to the potential risks caused by mechanical and electrical equipment.

It is very important that applications and installations meet all applicable safety requirements.

Each installer has an obligation to take responsibility to verify their knowledge and understanding of all applicable safety standards.

Any use which does not meet the safety requirements can damage equipment and injure the user. SHS s.r.l. does not consider itself responsible for, and assumes no liability for damage caused by handling products and / or improperly installed, or in cases where the customer has allowed, or executed, modifications and / or repairs not authorized by SHS s.r.l.

The SHS drives are devices for automation high performance capable of generating rapid movements and high forces.

Pay high attention, especially during installation and application development.

Only use equipment properly sized for the application..

The SHS devices are considered components for automation and are sold as finished products to be installed only by qualified personnel and in accordance with all local safety regulations.

The technicians must be able to recognize possible dangers that may result from programming, by changing parameter values and generally by the mechanical, electrical and electronic.

SHS s.r.l. recommends to always follow basic safety rules. Failure to heed them can result in injury to persons and / or property.

General precautions:

This manual is subject to change due to product improvement, specification changes or improvements of the manual

SHS s.r.l. is not responsible for damage to property and / or persons caused by faulty installation and / or unauthorized modifications of the product.



The damaged drive systems must not be installed or put into operation in order to avoid injury persons and damage to property. Changes or modifications made to the drive systems is prohibited and It involves the extinction of any right to warranty or of any obligation of responsibility.



Index

| TECHN | NICAL DATA | 4 |
|-------|------------------------------------|----|
| 1.1 | Power supply / Motor Connector | 4 |
| 1.2 | FIELDBUS Connector | 4 |
| 1.3 | Input/Output Connectors | 5 |
| 1.4 | DIP-SWITCH and Ethernet Connectors | 6 |
| 1.5 | Status LEDS | 6 |
| 1.6 | Protection / Display messages | 7 |
| 1.7 | Parameters setting | 8 |
| 1.8 | Mechanical dimension | 9 |
| CONN | ECTION | 10 |
| 2.1 | Installation note | 10 |
| 2.2 | AC Power Supply | 10 |
| 2.3 | DC Power Supply | 12 |
| 2.4 | Input / Outputs | 13 |
| 2.5 | Digital Inputs | 14 |
| 2.6 | Digital Outputs | 14 |
| 2.7 | Encoder Inputs | 15 |
| 2.8 | Analog Inputs/ Outputs | 16 |
| OPER/ | ATING MODE | 16 |
| 3.1 | PROFINET Protocol | 17 |
| 3.2 | Data communication via PROFINET | 17 |
| 3.3 | PROFINET control bits | 19 |
| 3.4 | ZSW bits positioning timing | 20 |
| 3.5 | Parameters | 23 |
| HT7 M | ODELS CODE | 27 |



1. TECHNICAL DATA

1.1 Power supply / Motor connector

| J1A(Left) | | |
|---------------|--------------------------------------------------------------------|--|
| SIGNAL | FUNCTION | |
| B2 | Phase B2 of the motor | |
| B1 | Phase B1 of the motor | |
| A2 | Phase A2 of the motor | |
| A1 | Phase A1 of the motor | |
| HVI | Power supply input DC (connect to HV0 or use as input DC power) | |
| GND | 0V power supply | |
| J1B (Right) | | |
| SIGNAL | FUNCTION | |
| AC1 | Power supply Vac | |
| AC2 | Power supply Vac | |
| HV0 | Rectified output | |
| AUX | Logic power supply input 24Vdc | |
| SHIELD | Shield | |
| 0S | 0V power supply Aux | |



1.2 FIELDBUS Connector

| J3 | SIGNAL | FUNCTION |
|----|--------------|----------------------------|
| 1 | 0V | |
| 2 | CL (CANL) | |
| 3 | RS- (RS485-) | Used only upgrade firmware |
| 4 | CH (CANH) | |
| 5 | RS+ (RS485+) | |



1.3 Input / Output Connectors

| J2A (Left) | SIGNAL | FUNCTION |
|------------|---------|------------------------------------------------|
| 1 | ENC_AH | Encoder A+ |
| 2 | ENC_AL | Encoder A- |
| 3 | ENC_BH | Encoder B+ |
| 4 | ENC_BL | Encoder B- |
| 5 | ENC_ZH | Encoder Z+ |
| 6 | ENC_ZL | Encoder Z- |
| 7 | ENC_COM | Encoder common (don't se in differential mode) |
| 8 | ENA/DIS | Input ENABLE/DISABLE |
| 9 | IN3 | Input IN3 – (CURRENT REDUCTION) |
| 10 | IN2 | Input IN2 - (DIRECTION) |
| 11 | IN1 | Input IN1 – (STEP IN) |

| | HT7 |
|---|-------------|
| | HE7 |
| | |
| | |
| | err |
| | JP STS |
| | SHS 2 |
| | |
| | < |
| | J2 |
| | |
| 1 | GN BS BS BS |
| < | |
| 2 | VO AU |
| | |
| | ACI A RE |
| | |

| JZB (Right) | SIGNAL | FUNCTION |
|-------------|------------|-----------------------------------------|
| 12 | OUT_COM | Output common (OUT1, OUT2, OUT3) |
| 13 | OUT1 | Output OUT1 - (default motor run) |
| 14 | OUT2 | Output OUT2 - (default Drive Ready) |
| 15 | OUT3 | Output OUT3 - (default unused) |
| 16 | IN_COM | Input common (IN1, IN2, IN3, ENA/DIS) |
| 17 | AN_IN0 | Analog Input IN0 |
| 18 | AN_IN1 | Analog Input IN1 |
| 19 | AN_IN2 | Analog Input IN2 |
| 20 | AN_OUT | Analog Output |
| 21 | GND_SIGNAL | 0V (relative at EXT_12V, AN_IN, AN_OUT) |
| 22 | EXT_12V | Output +12V (relative at GND_SIGNAL) |
| | | |



1.4 DIP SWITCH

| DIP1 | ON | OFF |
|------|----------------------------------|-----------------------------------|
| 1 | Insert termination CAN | Not used |
| 2 | Insert termination RS485 | Not used |
| 3 | Not used | Not used |
| 4 | Input function En / Dis = ENABLE | Input function En / Dis = DISABLE |



Only HT7xx PN, EC, EI model is supplied of double RJ45 interface (upper pictures). The RJ45 connections can be used interchangeably in PN and EI model.

| Phisical Features | Connection Type | Cable / Transmission type | Speed | Max Cable Lenght |
|----------------------|-----------------|-----------------------------------------------|--------------------------|---------------------|
| Electrical | RJ45 Connector | 100base-TX Shield cable CAT5 IEEE 802.3 | 100Mbit/s full duplex | 100 mt |

1.5 Status LEDS

| LED | FUNCTION | |
|-----|-------------|---------------------|
| RUN | Drive OK | Light ON |
| Kon | Drive Error | Light OFF |
| FRR | Drive Error | Light OFF |
| | Drive OK | Light ON |
| ете | Drive OK | Light fast blinking |
| 515 | Drive Error | Light slow blinking |





| | DISPLAY | DESCRIPTION |
|------------|---------|------------------------|
| HT7 | rdY | Drive OK at STOP motor |
| 111 | run | Motor in movement |
| HE ICE | dis | Drive DISABLE |
| • | ocur | Overcurrent Error |
| | tenP | Overtemperature Error |
| RUN ERR | uuoL | Undervoltage Error |
| STS | ouoL | Overvoltage Error |
| | rSt | Reset phase |
| | Onet | No connected |

1.6 Protection / Display messages

Drive is provided with protections against overtemperature, overvoltage, undervoltage, short-circuits among outputs and among outputs and the positive power pole, no-phase motor connection. If one of the mentioned conditions occurs, drive disables the power bridge and shows an error condition on the display.

To restore overcurrent protection tou must restart the unit.

(

The decimal point to the left indicates the status RX, while the one on the right indicates the status of the communication interface TX.



1.7 Parameters setting

By using the buttons below the display (hereinafter referred to as $[\vee]$, $[\sim]$, $[\wedge]$) you can parameterize the drive:

To access to main menù, press $[\vee] + [\sim]$, it will visualized "**Menu**" for 1 sec, after the parameter "**p001**" From the main menu to select the parameter to be changed press the button $[\vee]$ or $[\wedge]$. From main menù to visualize the actual value of parameter press $[\sim]$.

From the parameter to change the value press [V] or [\land]

From the parameter to store the value press the button [<>] for 1 sec and it will appear " **Memo** "

From the parameter to come back at main menù without modify any conditions, press [<>] less than 1 sec (don't will appear "**Memo**").

From the main menù to go out press [] + [].

| PARAMETER | FUNCTION |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------|
| p001 | Opar: when this parameter is stored, all parameters will be set to default value and it will appear "rst" then restart the driver |
| p003 | Current setting [A] |
| p006 | Setting step resolution (1/2,, 1/20) |
| p007 | Setting stand-by current (0, 25, 50, 100%) |
| p008 | Setting parameter resonance1 reduction (fd0,, fd4) |
| p009 | Setting parameter resonance2 reduction (small, big) |
| p010 | Setting wave mode (wav0, wav1) |
| p011 | Setting to operate high frequency |
| p013 | Setting toggle bit (0 - 1) |
| p014 | Enable refresh for the last polled parameter |
| p015 | Enable refresh status word |
| p016 | Motor Stopped when the driver communication fault |



| MODEL HT7 xx- | WEIGHT [gr] |
|---------------|---------------|
| WS-MB-CO-PB | 655 |
| PN-EC-EI | 720 |

www.shsitalia.it info:shsbox@shsitalia.it

9

ISO 9001 BUREAU VERITAS Certification



2. CONNECTIONS

2.1 INSTALLATION NOTES



DANGER OF ELECTRICAL SHOCK

ONLY QUALIFIED PERSONNEL SHOULD WORK ON THIS EQUIPMENT. DISCONNECT ALL POWER BEFORE WORKING ON EQUIPMENT. DANGEROUS VOLTAGES MAY EXIST AFTER POWER IS REMOVED! BEFORE WORKING ON EQUIPMENT CHECK DC BUS VOLTAGE OF DRIVES EACH TIME POWER IS REMOVED.

2.2 AC Power Supply

The transformer power is $P = Vac^*(Inf(tot) + 1)$ Where *P* is *VA* power, *Vac* is secondary voltage in Volts and Inf(tot) is the sum of all nominal currents set in all the drive to be supplied.

| | Unit | HT710 | HT720 | HT730 | HT740 |
|--------------------------|------|---------------|---------------|---------------|---------------|
| Vac nom | [V] | From 18 to 60 | From 18 to 60 | From 18 to 60 | From 18 to 90 |
| Vac max | [V] | 75 | 75 | 75 | 110 |
| Vac min | [V] | 15 | 15 | 15 | 15 |
| l max | [A] | 4 | 7 | 12 | 12 |
| l min | [A] | 1 | 1 | 1 | 1 |
| Operation Temperature | [°C] | 0 - 45 | 0 - 45 | 0 - 45 | 0 - 45 |
| Vdc aux | [V] | 24 | 24 | 24 | 24 |

NOTE: use a transformer with an isolated secondary, don't connect the secondary at ground.

Vac nom : Range value of voltage by which the drive can be powered.

Vac max: Opertative Maximum voltage. Over this limit, the protection of maximum voltage inhibits the drive.

Vac min: Operative Minimum voltage. Under this limit, the protection of minimum voltage inhibits the drive.

I max: Maximum value of phase current.

I min: Minimum value of phase current.

Operating temperature: For any temperature over 45°C and any current over 6A a forced ventilation is necessary.

Vdc aux: Logic power supply.



WIRING DIAGRAM:



In AC power mode do not connect GND signals between two or more HT7 drives:





| | Unit | HT710 | HT720 | HT730 | HT740 |
|--------------------------|------|---------------|---------------|---------------|-------------------|
| Vac nom | [V] | From 24 to 90 | From 24 to 90 | From 24 to 90 | From 24 to 125 |
| Vac max | [V] | 110 | 110 | 110 | 160 |
| Vac min | [V] | 20 | 20 | 20 | 20 |
| l max | [A] | 4 | 7 | 12 | 12 |
| l min | [A] | 1 | 1 | 1 | 1 |
| Operation Temperature | [°C] | 0 - 45 | 0 - 45 | 0 - 45 | 0 - 45 |
| Vdc aux | [V] | 24 | 24 | 24 | 24 |

2.3 DC POWER SUPPLY

Vdc nom : Range value of voltage by which the drive can be powered.

Vdc max: Operating Maximum voltage. Over this limit, the protection of maximum voltage inhibits the drive. Vdc min: Operating Minimum voltage. Under this limit, the protection of minimum voltage inhibits the drive. I max: Maximum value of phase current.

I min: Minimum value of phase current.

Operating temperature: For any temperature over 45°C and any current over 6A a forced ventilation is necessary.

Vdc aux: Logic power supply.

WIRING DIAGRAM:





2.4 Inputs / Outputs

Digital inputs and outputs pins are isolated from power.

- Single Ended inputs are NPN/PNP type selectable through COM-IN pin.
- Differential input are TTL compatible, and can be 24V compatible PNP through COM-ENC pin.
- Outputs are NPN/PNP type selectable through COM-OUT (10mA max for OUT1, 100mA max for OUT2 and OUT3). On request the outputs can be equipped with OptoMOS devices (maximum current 400mA, 60V).

Analog inputs and outputs pins are not isolated from power, they have range 0 to 10V.

INPUTS FEATURES:

| (IN1, IN2, IN3, ENABLE) | | | VOLTAGE LEVEL |
|-------------------------------------------------------------------------|------------------|---------------------|----------------------------------|
| LOW LEVEL | | FROM 0 TO 7V | |
| HIGH LEVEL | | FROM 10 TO 24V | |
| MAX CURRENT | | | 13mA |
| | | | |
| DIFFERENTIAL INPUTS (ENCAx, ENCBx, ENCZx) | тт | L | SINGLE ENDED 24V |
| DIFFERENTIAL INPUTS (ENCAx, ENCBx, ENCZx) LOW LEVEL | TT FROM 0 | L TO 2V | SINGLE ENDED 24V FROM 0 TO 6V |
| DIFFERENTIAL INPUTS (ENCAx, ENCBx, ENCZx) LOW LEVEL HIGH LEVEL | FROM 0 FROM 4 | L TO 2V TO 5V | FROM 0 TO 6V FROM 9 TO 24V |

| OUTPUTS | | VOLTAGE LEVEL |
|---------|---------|---------------------|
| | OUT ON | COM_OUT VOLTAGE -2V |
| | OUT OFF | 0V |
| | OUT ON | 2V |
| | OUT OFF | COM_OUT VOLTAGE |

| ANALOG INPUTS | VOLTAGE LEVEL |
|---------------|---------------|
| INPUT | FROM 0 TO 10V |
| OUTPUT | FROM 0 TO 10V |





2.5 Digital Inputs



2.6 Digital Outputs





2.7 Encoder Inputs







2.8 Analog Inputs / Outputs



Note: we suggest to use isolated inputs scheme, no electrical connections between control and drives.

3. OPERATING MODE

The driver can be operated in the following modes:

PROFINET



3.1 SETTING ON THE PROFINET MASTER

Use the device master file "GSDML-v2,31-SHS-HT7-20160125.xml" to configure your communication software on the master.

3.2 DATA COMMUNICATION VIA PROFINET

The data format used is Motorola ("Big Endian").

PROFINET structure:

| Protocol frame | User data | Protocol frame |
|----------------|--------------------------------------|----------------|
| (Header) | Parameter (PKW) – Process data (PZD) | (trailer) |

User data structure from MASTER to SLAVE (HT7 drive):

| PKW | | | | PZ | ZD |
|----------------------|----------------------|--------------------------|--------------------------|----------------------|----------------------|
| PKE | IND | PWE | | ZSW | HSW |
| 1 st word | 2 nd word | 3 rd word (H) | 4 th word (L) | 1 st word | 2 nd word |

- PKW: Parameter identifier value
- PZD: Process data
- PKE: Parameter idetifier
- IND: Index (not used. Set to 0)
- PWE: Parameter value

ZSW: Control word 1 (see pag.16)

HSW: Main setpoint (not used. Set to 0)

Parameter Identifier (PKE) (1st Word):

The parameter identifier (PKE) is always a 16-bit value. Bits 0 to 10 contain the number of the desired parameter (PNU). Refer to the parameter listing (Chapter 5.4) Bits 12 to 15 contain the task or reply identifier (AK).

| | PKE | |
|-------------|----------|------------|
| Bit 15(H)12 | Bit11 | Bit 100(L) |
| AK | Not used | PNU |

AK: Task or reply identifier PNU: Parameter number

| AK VALUE | MEANING |
|----------|-------------------------|
| 0 | No task |
| 1 | Request parameter value |
| 2 | Change parameter value |

17



User data structure from SLAVE (HT7 drive) to MASTER:

| PKW | | | | PZ | ZD |
|----------------------|----------------------|--------------------------|--------------------------|----------------------|----------------------|
| PKE | IND | PWE | | STW | HIW |
| 1 st word | 2 nd word | 3 rd word (H) | 4 th word (L) | 1 st word | 2 nd word |

PKW: Parameter identifier value

PZD: Process data

PKE: Parameter idetifier

IND: Index (not used)

PWE: Parameter value

STW: Status word 1 (see pag.16)

HIW: Main actual value (not used)

Parameter Identifier (PKE) (1st Word):

The parameter identifier (PKE) is always a 16-bit value.

Bits 0 to 10 contain the number of the desired parameter (PNU). Refer to the parameter listing (Chapter 5.4) Bits 12 to 15 contain the task or reply identifier (AK).

| PKE | | | | |
|-------------|----------|------------|--|--|
| Bit 15(H)12 | Bit11 | Bit 100(L) | | |
| AK | Not used | PNU | | |

AK: Task or reply identifier

PNU: Parameter number

| AK VALUE | MEANING |
|----------|------------------------------------------------------|
| 0 | No task |
| 2 | Transmit parameter value |
| 7 | Task not executable (with error number on word 4) |

| ERROR (WORD 4) | MEANING |
|----------------|--------------------------------------|
| 0 | No task |
| 1 | Parameter value cannot be changed |



3.3 PROFINET CONTROL BITS

BITS ZSW – MASTER ⇒ SLAVE

| BIT | VALUE | FUNCTION | REMARKS |
|-----------|-------------------|------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| 0 (L) | 1 – ON 0 - OFF | ON - Start RELATIVE positioning OFF - Stop RELATIVE positioning | This bit is ignored when absolute positioning or JOG function is active |
| 1 | 1 – ON 0 - OFF | ON - Start ABSOLUTE positioning OFF - Stop ABSOLUTE positioning | This bit is ignored when relative positioning or JOG function is active |
| 2 | | | |
| 3 | 1 – ON 0 - OFF | ON - Drive enable OFF - Dive disable (motor current=0) | To execute every postitioning command this bit must be set to 1 |
| 4 | 1 – ON 0 - OFF | ON - Reset Alarm | |
| 5 | | | |
| 6 | | | |
| 7 | | | |
| 8 | 1 – ON 0 - OFF | ON - Start Jog cw (infinite motion) OFF - Stop | This bit is ignored when relative/absolute positioning or JOGCCW function is active |
| 9 | 1 – ON 0 - OFF | ON - Start Jog ccw (infinite motion) OFF - Stop | This bit is ignored when relative/absolute positioning or JOGCW function is active |
| 10 | | | |
| 11 | 1 – ON 0 - OFF | ON - Set OUT3 OFF – Reset OUT3 | Set/reset OUT3 To use this function bit 12 must be set to 1 |
| 12 | 1 – ON 0 - OFF | ON - Enable outputs force OFF - Disable outputs set (Standard function on outputs) | This bit disable standard outputs functions and permit to force outputs through bits 13 and 14 of this word (ZSW) |
| 13 | 1 – ON 0 - OFF | ON - Set OUT1 OFF – Reset OUT1 | Set/reset OUT1 To use this function bit 12 must be set to 1 |
| 14 | 1 – ON 0 - OFF | ON - Set OUT2 OFF – Reset OUT2 | Set/reset OUT2 To use this function bit 12 must be set to 1 |
| 15 (H) | | Reserved for refresh Bit | |



BITS STW – SLAVE \Rightarrow MASTER

| BIT | VALUE | FUNCTION | REMARKS |
|-----------|-------------------|-----------------------------------------------------------------------------------|---------|
| 0 (L) | 1 - ON 0 - OFF | ON - Drive ready OFF - Drive fault or disable | |
| 1 | 1 - ON 0 - OFF | ON - Motor running OFF - Motor stop | |
| 2 | 1 - ON 0 - OFF | ON - Drive disable OFF - Drive enable | |
| 3 | 1 - ON 0 - OFF | ON - Protection active OFF - Protection not active | |
| 4 | 1 - ON 0 - OFF | ON - IN1 active OFF - IN1 not active | |
| 5 | 1 - ON 0 - OFF | ON - IN2 active OFF - IN2 not active | |
| 6 | 1 - ON 0 - OFF | ON - IN3 active OFF - IN3 not active | |
| 7 | 1 - ON 0 - OFF | ON - OUT1 active OFF - OUT1 not active | |
| 8 | 1 - ON 0 - OFF | ON - OUT2 active OFF - OUT2 not active | |
| 9 | 1 - ON 0 - OFF | ON - Rotation CW OFF - Rotation CCW | |
| 10 | 1 - ON 0 - OFF | ON - Max frequency reached OFF - Max frequency not reached | |
| 11 | 1 - ON 0 - OFF | ON - Positioning completely executed OFF - Positioning not completely executed | |
| 12 | 1 - ON 0 - OFF | ON - Axis zeroing executed OFF - Axis zeroing not executed | |
| 13 | 1 - ON 0 - OFF | ON - EXTRA-SWITCH reached OFF - EXTRA-SWITCH notreached | |
| 14 | 1 - ON 0 - OFF | ON - Error durig encoder positioning OFF - OK | |
| 15 (H) | 1 - ON 0 - OFF | Reserved for refresh Bit | |

3.4 ZSW BITS POSITIONING TIMING





ZSW bit Jog Mode

TA = time to START motor: maximum 30 ms

TB = time between falling edge and rising edge of start signal: minimum 50 ms

COMMAND SEQUENCE TO EXECUTE A POSITIONING:

RELATIVE POSITIONING:

- Enable driver (ZSW BIT 3)
- Set relative quote (PNU 7)
- Set start relative positioning bit (ZSW BIT 0) to 1
- Wait TA time to START motor (minimum 30ms) or front 0-1 of motor running bit (STW BIT 1)
- Wait end of positioning (front 1-0) or zero level of motor running bit (STW BIT 1)
- Set start relative positioning bit (ZSW BIT 0) to 0
- Wait TB time (minimum 50ms) and start new positioning. If TB is not respected motor may be not start

ABSOLUTE POSITIONING:

- Enable driver (ZSW BIT 3)
- Set absolute quote (PNU 8)
- Set start absolute positioning bit (ZSW BIT 1) to 1
- Wait TA time to START motor (minimum 30ms) or front 0-1 of motor running bit (STW BIT 1)
- Wait end of positioning (front 1-0) or zero level of motor running bit (STW BIT 1)
- Set start absolute positioning bit (ZSW BIT 1) to 0
- Wait TB time (minimum 50ms) and start new positioning. If TB is not respected motor may be not start

JOG CW / JOG CCW:

- Enable driver (ZSW BIT 3)
- Set JOG CW (ZSW BIT 8) or JOG CCW (ZSW BIT 9) to 1 (start motor)
- Wait TA time to START motor (minimum 30ms) or front 0-1 of motor running bit (STW BIT 1)
- Set JOG CW (ZSW BIT 8) or JOG CCW (ZSW BIT 9) to 0 (stop motor)
- Wait zero level of motor running bit (STW BIT 1)
- Wait TB time (minimum 50ms) to start new JOG. If TB is not respected motor may be not start





HOMING:

- Connect switch or proximity sensor (NO or NC) to IN1
- Enable driver (ZSW BIT 3)
- Set maximum frequency PNU 1 (in homing function it represents home search speed)
- Set minimum frequency PNU 0 (in homing function it represents sensor disengage speed)
- Start homing (PNU 18) with a parameter 0x01 (HEX) for NC sensor or 0x11 (HEX) for NO sensor on IN1

Sensor not engaged:

When you write PNU 18 the motor starts immediately in CCW direction with maximum speed, then it stops on sensor and starts in CW direction with minimum speed to disengage sensor then stops and set position register (PNU 10) to 0.

It's very important that the motor stops with sensor engaged without get over it. To avoid this it is possible reduce maximum frequency or reduce ramp (PNU 2)

Sensor engaged:

When you write PNU 18 the motor starts immediately in CW direction with minimum speed to disengage the sensor then it stops and set position register (PNU 10) to 0.

NOTE: If motor starts in wrong direction during homing you must change motor phases connection (swap A1 with A2 clamps).



3.5 PARAMETERS

| PNU | FUNCTION | PARAMETER |
|-----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Setting of minimum frequency Motor rotation start frequency | From 1 to 10000 Hz |
| 1 | Setting of maximum frequency Motor rotation working frequency | From 1 to 20000 Hz |
| 2 | Setting of ramp inclination If motor is running, this parameter will be acquired to the next motion command. | From 1 to 255 expressed in ms * 10 |
| 3 | Setting of motor resolution If motor is running, this parameter will be acquired to the next motion command. | If the sent = 128 full step mode = 64 1/2 step mode = 32 1/4 step mode = 16 1/8 step mode = 4 1/32 step mode = 2 1/64 step mode = 1 1/128 step mode = 1040 1/2.5 step mode = 1020 1/5 step mode = 1010 1/10 step mode = 1005 1/20 step mode = 1002 1/50 step mode = 1001 1/100 step mode |
| 4 | Mode setting of electric current reduction Set % or current reduction when motor is stopped | If the sent = 0 current = 0 (max reduction) = 1 no reduction = 2 reduction to 25% = 3 reduction to 50% |
| 5 | Time setting of electric current reduction Time after which current reduction (from 0 to 255) must occur on a time basis of 32 ms | From 0 to 255 |
| 6 | Current setting Set motor current | From 0 to 10000 mA |
| 7 | Setting of relative quote Indicate the relative positioning with respect to the present position of the motor to be carried out at the next START (with control bit) or TRIGGER START expressed in 1/128 step | From -2147483647 to 2147483647 |



| PNU | FUNCTION | PARAMETER |
|-----|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
| | Setting of absolute quote | From -2147483647 to 2147483647 |
| 8 | Indicate the absolute positioning with respect to home position to be carried out at the next START (with control bit) or TRIGGER START expressed in 1/128 step | |
| | Setting of home position | From -2147483647 to 2147483647 |
| 9 | Drive associates the entered value to home position of the motor | |
| | Present position | From -2147483647 to 2147483647 |
| 10 | Position register, you can read or write this value. (expressed in 1/128 step) | |
| | Present frequency | READ ONLY REGISTER |
| 11 | Motor rotation frequency | |
| | Final position | READ ONLY REGISTER |
| 12 | Motor destionation quote | |
| | Trigger start (logic AND) | Use only less significant byte: |
| | It defines the Input or the inputs and the respective Levels, which must be enabled for carrying out the START by an external command. | The 4 less significant bits indicate the input or the inputs, which must be enabled for |
| 13 | | START (1= enabled input). |
| | | The next 4 bits indicate the level of these inputs (1= input active at high level) |
| | Trigger stop (logic AND) | Use only less significant byte: |
| 14 | It defines the Input or the inputs and the respective Levels, which must be enabled for carrying out the STOP by an external command. USE ONLY ONE TRIGGER STOP AT TIME (PNU 14 OR PNU 15) | The 4 less significant bits indicate the input or the inputs, which must be enabled for STOP (1= enabled input). |
| | | The next 4 bits indicate the level of these inputs (1= input active at high level) |
| | Trigger stop (logic OR) | Use only less significant byte: |
| 15 | It defines the Input or the inputs and the respective Levels, which must be enabled for carrying out the STOP by an external command. USE ONLY ONE TRIGGER STOP AT TIME (PNU 14 OR PNU 15) | The 4 less significant bits indicate the input or the inputs, which must be enabled for STOP (1= enabled input). |
| | | The next 4 bits indicate the level of these inputs (1= input active at high level) |
| | Trigger home (logic AND) | |
| 16 | It defines the Input or the inputs and the respective Levels, which must be enabled for carrying out the HOME by an external command and stop motor. | |
| | | |



| PNU | FUNCTION | PARAMETER |
|-----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| | Trigger zerofly (logic AND) | Use only less significant byte: |
| 17 | It defines the input or the inputs and the respective levels, which must be enabled for carrying out zeroing of the value in the present motor position, when this condition occurs, and the value to be done on occasion of this condition. You must be set also ZEROFLY QUOTE (parameter 21) and/or MASK ZEROFLY OLIOTE (parameter 20) | The 4 less significant bits indicate the input or the inputs, which must be enabled for ZERO AT FLIGHT (1= enabled input). |
| | | The next 4 bits indicate the level of these inputs (1= input active at high level) |
| | Axis zeroing | Use only less significant byte: |
| 18 | It defines the input and relative level where zero switch will be connected and it carries out axis zeroing. The zeroing phase includes: CCW motor start; the search of zero switch with rotation at max speed; stop on zero switch; disengagement of zero switch at min. speed and zeroing of absolute position. | The 4 less significant bits indicate the input or the inputs, which must be enabled for AXIS ZEROING (1= enabled input). |
| | | The next 4 bits indicate the level of these inputs (1= input active at high level) |
| | Limit switch | Use only less significant byte: |
| 19 | It defines the input and the relative level where the limit switch will be connected. When the switch will be intercepted, it will cause the immediate motor stop and it allow only the opposite wise motion. The command activates this function until its disengagement through a new command with no specified input (Parameter=0). | The 4 less significant bits indicate the input or the inputs, which must be enabled for LIMIT SWITCH (1= enabled input). |
| | | The next 4 bits indicate the level of these inputs (1= input active at high level) |
| | Mask zerofly quote | From 0 to 2147483647 |
| 20 | Indicate the mask positioning to be done in the same rotation direction to enable zerofly trigger | |
| | Zerofly quote | From 0 to 2147483647 |
| 21 | Indicate the positioning to be done in the same rotation direction since when the condition expressed on the trigger zerofly byte | |
| | Low noise mode | If the sent |
| 22 | | = 2 \rightarrow enable = 0 \rightarrow disable |
| 23 | Protection type | If read = 0 → drive ready = 1 → power supply out of range = 2 → thermal protection = 3 → short circuit |



| PNU | FUNCTION | PARAMETER |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 24 | Protection active / reset | If read = 0x00→ drive ready = 0x02→ short circuit = 0x04→ thermal protection = 0x08→ power supply undervoltage = 0x10→ power supply overvoltage (in previous profibus versions in case of protection this value is set to 1) If write 0 reset permanent protection (short circuit or phase disconnected) the other protections are automatically resetted when the error condition disappear |
| 25 | Software release | READ ONLY REGISTER |
| 26 | Power supply voltage [Vdc] | READ ONLY REGISTER |
| 27 | Drive temperature [°C] | READ ONLY REGISTER |
| 50 | Encoder position Encoder position register, you can read or write this value. (expressed in encoder steps) This value counts all fronts of two encoder phases | From -2147483647 to 2147483647 |
| 51 | Encoder mode | If Write 0 → no encoder feedback. You can read encoder but the drive don't use it to control position 1 → encoder enabled without error detection 2 → encoder enabled with error detection |
| 52 | Set encoder pulse/revolution | From 0 to 2147483647 |
| 53 | Set encoder fault steps Set encoder steps to detect positioning error. | From 0 to 2147483647 |
| 54 | Encoder Index search frequency It defines the search index frequency | From 1 to 5000 Hz |
| 55 | Encoder index search mode Indicate 4 modes to search index | 0x01= search CW 0x02= search CCW 0x11= search CW and set position to 0 0x12= search CCW and set position to 0 |



4. HT7 MODELS CODE

HT7xxKK - yyyyy / Zzz

| 7 | _ 7 | |
|---|-----|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | | SPECIAL VERSION: Dzz = Dedicate Software Szz = Modify Hardware (*) |
| | | OPTION: View the following table |
| | | FIELDBUS: WS = RS485 SHS Protocol MB = Modbus CO = CanOpen PB = Profibus PN = ProfiNet EC = EtherCat EI = Ethernet/IP MT = ModbusTCP |
| | | SIZE: 10 = 4A 1860Vac or 2490Vdc |

The defaul configuration it:

• Input from 12 to 24V

| CODE | yyyyOPTION | |
|------|--------------------------|-----|
| 1 | Differential Encoder | |
| 2 | Encoder TTL | |
| 4 | Input TTL | |
| 8 | OUT1 PNP OptoRelay | (*) |
| 16 | OUT1 NPN/PNP | |
| 32 | OUT2 PNP OptoRelay | (*) |
| 64 | OUT2 NPN/PNP | |
| 128 | EEprom special Firmware | |
| 256 | Analog Input | |
| 512 | Fieldbus crimp connector | (*) |
| 1024 | Fieldbus DB9 connector | (*) |
| 2048 | IO crimp connector | (*) |

(*) not available for this drive

EXAMPLE 1: the default configuration will become option 0 (00000)

EXAMPLE 2: TTL Input + OUT1 NPN/PNP relay + EEprom Firmware, will become option 4+16+128 = 148 (00148)

www.shsitalia.it info:shsbox@shsitalia.it

20 = 7A 18..60Vac or 24..90Vdc 30 = 12A 18..60Vac or 24..90Vdc 40 = 12A 18..90Vac or 24..125Vdc







S.H.S. s.r.l. Via F.lli Rosselli, 29 20027 Rescaldina (MI) – ITALY

Tel. +39 0331 466918 Fax. +39 0331 466147 www.shsitalia.it