

ISTRUZIONI COLLEGAMENTO BLOCCHETTI IN/OUT BLOCK IN/OUT CONNECTING INSTRUCTIONS

- 1) Collegare il bloccetto ① d'ingresso o d'uscita ② al componente di sicurezza valvola SAFE AIR[®] utilizzando le due viti TCE ③.
- 2) Avvitare la boccola di giunzione sul bloccetto fino in battuta.
(Per garantire una tenuta perfetta si consiglia di utilizzare del sigillante sul filetto G1/4" o G3/8").
- 3) Svitare leggermente la boccola ④ fino ad avere un piano dell'esagono parallelo al corpo del bloccetto ① o ② (vedi figura).
- 4) Inserire la boccola ④ nel gruppo Syntesi[®].
- 5) Avvitare le due viti autofilettanti ⑤ nel gruppo Syntesi[®] con coppia di serraggio 0.4 Nm max (SY1) e 2.5 Nm max (SY2).

- 1) Connect the inlet ① or outlet ② plate to the safety component SAFE AIR[®] valve using the two TCE screws ③.
- 2) Screw the connecting bushing onto the input or output plate as far as it will go.
(Use sealant on the G1/4" or G3/8" thread to provide a further seal).
- 3) Unscrew the bushing slightly until two surfaces of the hexagon are parallel to the body of plate ① or ② (see diagram).
- 4) Insert the bushing ④ into the Syntesi[®] unit.
- 5) Tighten the two self-tapping screws ⑤ in the Syntesi[®] unit to a torque of 0.4 Nm max (SY1) and 2.5 Nm max (SY2).

